



**INSERTING AND FORMING TOOL - STATOR  $\varnothing_{i.d.}=220\text{mm}$ .  
RISOMAT MACHINE**



B1077



[www.bennettinternacional.com](http://www.bennettinternacional.com)

